

Mobile Phones	PC/Laptop		Gaming Devices
Apple	Apple	ASUS	Nintendo
iPad Mini 6, iPad Pro 11, iPad Pro(12.9") (5th generation), iPhone 15 Pro Max, iPhone 15 pro, iPhone 15	Macbook air, Macbook Pro(2021), Macbook Pro (M1, 2020), MacBook Pro (13", M2, 2022), Macbook pro (Touch bar) #2, iMac (2023), iMac (2021, M1), iMac (2019)	ASUS ROG phone11	Switch, Switch Lite
Samsung	Lenovo		Sony
Galaxy S9*, Galaxy S9 plus*, Galaxy S10 Plus, Galaxy S20 5G, Galaxy S21, Galaxy S21 Ultra 5G, Galaxy S22+, Galaxy S22, Galaxy S23, Galaxy S23+, Galaxy S23 Ultra, Galaxy S24+, Note 8*, Note 9*, Note 10, Note 20, A52, A90, Galaxy zFlip5, Galaxy Tab S5e*, Galaxy Tab S7, Galaxy Z FOLD 5	Legion Y7000P (For Gaming HP), Legion Y9000K (For Gaming HP), Legion 7000K (Desktop, For Gaming HP), LenovoThinkPad E470C Windows 10 64, LenovoThinkPad E470C Windows 11 64		PS5
Xiaomi	Asus		
MI MIX3, MI Max 3, MI 9 Pro, XiaoMi 12 Pro, XiaoMi 13, XiaoMi 14, Xiaomi MIX Flod 3, Mi POCO X3 Pro, XiaoMi POCO X4 Pro (Global), Redmi 9, Redmi Note11PRO, Redmi K50 Pro, Mi Pad6, Black Shark gaming phone 3	Asus TX2, Asus ROG 5SD, Asus ROG G512L		
Huawei	Alienware		
Mate60 Pro, Mate50 Pro, Nova 6 5G, Mate 30, Mate 40 Pro, P50 Pro, P40, P30, P20	Alienware X15 R2, Alienware M15R3, Alienware Aurora R8		
OnePlus	Razer		
One Plus 6T (A6013), One Plus 7Pro, One Plus 11	Razer Blade 16		
Oppo	Microsoft		
Reno Ace (Need Open OTG connect), Reno 5 Pro 5G, OPPO Reno6 pro, Reno 6 5G, Reno 7 Pro, Reno 10, Find X6, FindX3	Surface Pro 4		
Realme	HP		
Realme X7	Omen 8		
Vivo			
Z5 (Need Open OTG connect), X60, X70			
Google			
Pixel 8pro, Pixel 8, Pixel 7A, Pixel 7pro, Pixel 7, Pixel XL, Pixel 5A, Pixel 4			
Sony			
XZ3, Xperia 10V, Xperia 1 IV 5G			
LG			
v40, G8 ThinQ			

Note: The functionality of the USB-C may vary depending on the device
 *When used with this device, press and hold the central button on the headphones remote to end the call
 **Voice calls via USB-C are not supported with this device