



JBL500, JBL800, JBL900, JBL Center simple setup guide

thank you for choosing JBL. For more than 50 years, JBL has been involved in every aspect of musical and film recording and reproduction, from live performances to monitoring the recordings you play in your home, car or office.


We're confident that the JBL loudspeakers you have chosen will provide every note of enjoyment that you expected – and that when you think about purchasing additional audio equipment for your home, car or office, you will once again choose JBL.

Please take a moment to complete the enclosed profile card. It enables us to keep you posted on our latest advancements, and helps us to better understand our customers and to build products that meet their needs and expectations.


JBL Consumer Products


One. Speaker Placement

JBL500, JBL800




JBL900






JBL Center




two. Speaker Connections

Connection Tips



Speakers and electronics terminals have corresponding (+) and (-) terminals. It is important to connect both speakers identically: (+) on the speaker to (+) on the amplifier and (-) on the speaker to (-) on the amplifier. Wiring "out of phase" results in thin sound, weak bass and a poor stereo image.



Troubleshooting

If there is no sound from any of the speakers, check the following:

- Receiver/amplifier is on and a source is playing.
- Review proper operation of your receiver/amplifier.

If there is no sound coming from one speaker, check the following:

- Check the "Balance" control on your receiver/amplifier.
- Check all wires and connections between receiver/ amplifier and speakers.
- Make sure all wires are connected. Make sure none of the speaker wires are frayed, cut or punctured.

If the system plays at low volumes but shuts off as volume is increased, check the following:

- Check all wires and connections between receiver/ amplifier and speakers.
- Make sure all wires are connected. Make sure none of the speaker wires are frayed, cut or punctured.
- If more than one pair of main speakers is being used, check the minimum impedance requirements of your receiver/amplifier.

If there is low bass output, check the following:

• Make sure the polarities (+ and -) of the left and right "Speaker Inputs" are connected properly.

If there is no sound from the center speaker, check the following:

- Make sure that your receiver's Center Channel Mode is in the "normal" or "wide" position. If it is in the "phantom" position, the center speaker will not play.
- Check all connections between processor/amplifier and the center speaker.

Specifications

Frequency Response (-6dB): Recommended Maximum Power Handling*: Sensitivity @ 1 watt/1 meter: Nominal Impedance: Crossover Frequency: Woofer: Tweeter: Dimensions (H x W x D):

Weight (each):

JBL500

75Hz – 20kHz

50 watts 86dB 8 ohms 2200Hz 5-1/4" 2" paper cone 11 x 6-1/2 x 7-1/4 inches 279 x 165 x 184mm 7 lbs/3.2 kg

JBL900

100 watts

88dB

8 ohms

3500Hz

55Hz – 20kHz

6-1/2" video shielded

12mm video shielded

813 x 229 x 203mm

32 x 9 x 8 inches

25 lbs/11.4 kg

Frequency Response (-6dB): Recommended Maximum Power Handling*: Sensitivity @ 1 watt/1 meter: Nominal Impedance: Crossover Frequency: Woofer: Tweeter: Dimensions (H x W x D):

Weight (each):

*The maximum recommended amplifier power rating will ensure proper system headroom to allow for occasional peaks. We do not recommend sustained operation at these maximum power levels. Occasional refinements may be made to existing products without notice, but will always meet or exceed original specifications unless otherwise stated.





JBL Consumer Products 250 Crossways Park Drive, Woodbury, NY 11797 8500 Balboa Boulevard, Northridge, CA 91329 1-800-336-4JBL (4525) (USA only)

© 1998 JBL, Incorporated. JBL is a registered trademark of JBL, Incorporated. 4/98 ۞ Part No. 234794

H A Harman International Company

JBL800

52Hz – 20kHz

100 watts 89dB 8 ohms 3200Hz 8" 12mm 32 x 9 x 8 inches 813 x 229 x 203mm 25 lbs/11.4 kg

JBL Center

90Hz – 20kHz

100 watts 90dB 8 ohms 7500Hz 2 x 4-1/2" 2-1/2" fiber cone 6-1/2 x 18-1/2 x 5-5/8 inches 165 x 470 x 143mm 10 lbs/4.5 kg

Note: The speaker grilles are not removable on any of the models listed in this manual.

